

# **Growatt** | Different WiFi module type from Growatt

| Marketing Department

### WiFi module difference

Difference	Wi-Fi-E (1)	Wi-Fi-E (2)	Wi-Fi-S
SN Begin	4Kxxxxxxxx	IUBxxxxxxx	SARHxxxxxx
LED	1 LED	3 LEDs (red, green, blue)	3LEDs (red, green, blue)
How to configurate	Configure via ShinePhone APP only	Configure via ShinePhone APP only	Configure via ShinePhone APP / WiFi module build in server
New and old replacement	Stop production in Sep. 2017	Start Sep. 2017	Sample testing state Will take place of previous version in 2019

Note: For more details information, please refer to the rated quick installation guide



# Why 3 LEDs

#### Make the installer better understand where is the communication state:

Red LED flash — Inverter and WiFi module communication is OK

**Green LED flash** — Inverter, WiFi module and Router communication is OK

Blue LED flash — Communication succeed built


inverter, WiFi, router and Growatt server communication is OK



# Why add build in server

## For troubleshooting

a. Configure WiFi module with the router information, when failed with ShinePhone APP



b. Check WiFi module build in server setting parameter, set inverter time, etc.

## For fix IP setting

You can turn off DHCP, and set the static IP address to WiFi module

